

INTUITIVE NAVIGATION IN ELECTRICAL NETWORKS

COMPREHENSIVE INSTRUMENTS FOR MEASUREMENT AND MONITORING OF POWER SYSTEMS





Panel installation devices for a clear view into electrical networks



The SINEAX AM-SERIES devices are compact instruments to measure and monitor in heavy current grids. They excel in display quality and intuitive operation. The devices provide a wide range of functionalities which may even be extended by optional components. They are connected to the process environment by communication interfaces, via digital I/Os, analog outputs or relays.

The devices have been designed for universal use in industrial plants, building automation or in energy distribution.

Nominal voltages of up to 690 V and measurement category CATIII can be directly connected in low voltage systems.

The universal measuring system permits the direct use of the devices in any type of grid, from single-phase mains through to 4-wire unbalanced load systems.

The AM series devices may be completely adapted to requirements on site via TFT display. Versions with an Ethernet interface permit webpage configuration without any special software.

CLEAR

High resolution, colour TFT display for the pin-sharp indication of measured data

Consistently visible status information (alarms, password protection, data recording, time/date and much more)

Clear design

INTUITIVE

Easy device operation with language-specific plain text menu guidance

Topical arrangement of measured data information for quick access to desired data

Service area for maintenance and commissioning

MULTIFUNCTIONAL

Varied monitoring options via limit values and their logical linkage

Central alarm function via display or Webpage

Alarm list with plain-text information for a quick plant status overview

FLEXIBLE

Universal measuring inputs for any type of grid

Freely selectable mean value and meter measuring variables

Configurable access authorisation


SCALABLE

Combinable device version (functionality, interfaces, I/Os, power supply)

Front dimension options (96x96 or 144x144mm)

Integration as a standard object into the SMARTCOLLECT software





ADVANCED MONITOR

MEASURED VALUES

MEASURED VALUE GROUP

INSTANTANEOUS VALUES

U, I, IMS, P, Q, S, PF, LF, QF ...

Angle between voltage phasors

Min/max of instantaneous values with time stamp

EXTENDED REACTIVE POWER ANALYSIS

Total reactive power, fundamental frequency, harmonics cosφ, tanφ of fundamental frequency with min values in all quadrants

HARMONICS ANALYSIS (ACCORDING TO EN 61 000-4-7)

Total harmonics content THD U/I and TDD I Individual harmonics U/I up to 50th

IMBALANCE ANALYSIS

Symmetrical components (positive, negative, zero sequence system) Imbalance (from symmetrical components)

Deviation from U/I mean value

ENERGY BALANCE ANALYSIS

Meters for the demand/supply of active/reactive power, high/low tariff, meters with selectable fundamental variable

Power mean values active/reactive power, demand and supply, freely definable mean values (e.g. phase power, voltage, current and much more).

Mean value trends

OPERATING HOURS

3 operating hour counters with programmable running condition (only AM1000/AM3000)

Operating hours of the device

APPLICATION

Transparent monitoring of present system state

Fault detection, connection check, sense of rotation check

Determination of grid variable variance with time reference

Reactive power compensation

Verification of specified power factor

Evaluation of the thermic load of equipment

Analysis of system perturbation and consumer structure

Equipment overload protection Fault/earth contact detection

Preparation of (internal) energy billing

Determination of energy consumption versus time (load profile) for energy management or energy efficiency verification

Energy consumption trend analysis for load management


Monitoring of service and maintenance intervals of equipments

DEMAND / SUPPLY / INDUCTIVE / CAPACITIVE

The devices of the SINEAX AM-SERIES provide information for all of the four quadrants. Depending on whether the measured system is considered from a generator or consumer perspective, the interpretation of the quadrants changes: The energy formed from active power in Quadrants I+IV can then be regarded, e.g., as supplied or demanded active energy. In order to facilitate an independent

interpretation of the 4-quadrant information, the terms demand, supply as well as inductive or capacitive load are avoided in the display of data. They are expressed by stating Quadrant I, II, III or IV or a combination of these.

The energy direction may be actively switched by selecting the generator or consumer arrow system. This inverts the direction of all currents.






DISPLAY OPTIONS



MAIN MENU - accessible via ESC


The language-specific main menu arranges the available measured data in easily comprehensible groups. AM2000 and AM3000 also provide the lateral help bar with further information concerning operation.

The status bar in the top right-hand corner is always available and displays the current statuses of alarm monitoring, the password protection system and data recording as well as time / date.




INSTANTANEOUS VALUES E

The instantaneous values of voltages, currents, power values, power factors as well as imbalance values and their min/max values are provided either in numbers or graphically in an x/y matrix.



ENERGY


Contains all values required for the preparation of the energy balance, in particular, energy meters as well a mean values with progression and trend.



POWER SYSTEM MONITORING


HARMONICS

Graphic representation of harmonics of all currents and voltages with TDD/THD. Reading option for individual harmonics.



PHASOR DIAGRAM

Time-correct display of voltage and current phasors and power factors of all phases. Incorrect phase sequences false senses of rotation or reverse currents can thus be safely recognised.



ALARMS

This list displays the statuses of all monitoring functions, possibly including the status of the allocated output. The first entry is the higher-ranking collective alarm which can be reset here.



WAVEFORM

AM1000 and AM3000 displays the waveform of voltages and currents in additionally.

MONITORING AND ALARMS


The instruments of the AM series support the on-site analysis of acquired measured data in order to initiate directly immediate or delayed measures without involving a separate control. This facilitates the protection of equipment and also monitoring of service intervals.

The following items are available:

- 12 limit values
- 8 monitoring functions with 3 inputs each
- 1 collective alarm as a combination of all monitoring functions
- 3 operating hour counters with definable running conditions

The available digital outputs may be used directly for the transmission of limit values and monitoring functions as well as the resettable collective alarm.

A text may be allocated to each monitoring function which is used both for the alarm list and the event entries in the datalogger.



DATA RECORDING

The devices may be equipped with a high-performance data logger which has the following recording options in its comprehensive version:

• PERIODIC DATA

Selectable measured values are saved in regular intervals, e.g. to acquire load profiles (intervals of 10s to 1h) or periodic meters readings (e.g. daily, weekly, monthly).

EVENTS


A type of logbook which records the occurrence of events together with time information: Triggering and declining of monitoring functions, changes in configuration, power cuts and much more.

• DISTURBANCE RECORDER (AM1000/AM3000 ONLY)

Recording of current and voltage progression in case of disturbances on basis of 1/2 cycle RMS values. In AM3000, the additional registration of the waveform during the disturbance is also possible. This type of registration corresponds to the requirements of the EN 61000-4-30 power quality standard.

The event list and the recordings of the disturbance recorder may be visualised right on the device. More extensive analyses are available via the webpage of the device.

An SD card is used as a memory element by AM2000/AM3000. AM1000 uses an internal memory element.





POWER SYSTEM MONITORING

TECHNICAL DATA

INPUTS

NOMINAL CURRENT 1 ... 5 A (max. 7.5 A)

Maximum 7.5A

10 A permanent Overload capacity

100 A, 5x1 s, interval 300 s

57.7 ... 400 V_{LN}, 100 ... 693 V_{LL}
480 V_{LN}, 832 V_{LL} (sinusoidal)
480 V_{LN}, 832 V_{LL} permanent
800 V_{LN}, 1386 V_{LL}, 10x1 s, interval 10 s **NOMINAL VOLTAGE** Maximum Overload capacity

42 ... <u>50</u> ... 58 Hz, 50.5 ... <u>60</u> ... 69.5 Hz Nominal frequency

Up to 60th harmonic Measurement TRMS

POWER SUPPLY VARIANTS

100 ... 230 V AC/DC (AM1000) Nominal voltage

110 ... 230 V AC, 130 ... 230 V DC

(AM2000/3000)

110 ... 200 V AC, 110 ... 200 V DC

(AM2000/3000)

24 ... 48 V DC (AM1000/2000/3000)

UNINTERRUPTIBLE POWER SUPPLY (UPS)

Type (3,7 V) VARTA Easy Pack EZPAckL, UL listed MH16707

TYPES OF CONNECTION

Single phase or split phase (2-phase system)

3 or 4-wire balanced load

Only AM1000/AM3000: 3-wire balanced load [2U, 1I]

3-wire unbalanced load, Aron connection

3 or 4-wire unbalanced load 4-wire unbalanced load, Open-Y

I/O-INTERFACE

ANALOG OUTPUTS (optional) Linearization Linear, kinked

±20 mA (24 mA max.), bipolar Range

±0.2% of 20 mA Accuracy

Burden $\leq 500 \,\Omega \,(\text{max. } 10 \,\text{V/} 20 \,\text{mA})$

DIGITAL INPUTS PASSIVE

Nominal voltage 12/24 V DC (30 V max.)

DIGITAL INPUTS ACTIVE (optional) Open circuit voltage $\leq 15 \text{ V}$

DIGITAL OUTPUTS

Nominal voltage 12/24 V DC (30 V max.) Nominal current 50 mA (60 mA max.)

FAULT CURRENT MONITORING For grounded systems (optional)

Number of meas. channels 2 (2 measurement ranges each) Measurement range 1 (1A) Earth current measurement Measuring transformer 1/1 up to 1/1000 A · Alarm limit 30 mA up to 1000 A Measurement range 2 (2mA)RCM with connection monitoring

· Measuring transformer Residual current transformer 500/1 up

to 1000/1 A

· Alarm limit 30 mA up to 1 A

TEMPERATURE INPUTS (optional)

Number of channels

Pt100 / PTC; 2-wire Measurement sensor

RELAYS (optional)

Contacts Changeover contact

Load capacity 250 V AC, 2 A, 500 VA; 30 V DC, 2 A, 60 W **BASIC UNCERTAINTY ACCORDING IEC/EN 60688**

AM1000/2000 AM3000 ±0.2% ±0.1% Voltage, current ±0.5% Power $\pm 0.2 \%$ Power factor $\pm 0.2^{\circ}$ ±0.1° ±0.01 Hz Frequency Imbalance U, I $\pm 0.5\%$ ±0.5% Harmonic

±0.5% Class 1 Class 0.5S Active energy (EN 62053-22) Reactive energy Class 1 Class 0.5S (EN 62053-24)

INTERFACES

THD U, I

ETHERNET Standard (AM3000), optional (AM1000/AM2000)

Physics Ethernet 100Base TX; RJ45 socket

Mode 10/100 MBit/s, full/half duplex, autonegotiation Protocols Modbus/TCP, http, NTP (time synchronisation)

IEC61850 option

Ethernet 100Base TX; RJ45 socket, 2 ports **Physics** 10/100 MBit/s, full/half duplex, autonegotiation Mode

IEC61850, NTP **Protocols**

PROFINET 10 optional Conformance class CC-B

Physics Ethernet 100BaseTX, RJ45-Buchsen, 2 ports Mode 10/100 Mbit/s, full/half duplex, auto-negotiation

PROFINET, LLDP, SNMP Protocol

MODBUS/RTU Standard (AM2000), optional (AM1000/AM3000)

RS-485, max. 1200 m (4000 ft) **Physics**

Baud rate 9.6 to 115.2 kBaud

TIME REFERENCE Internal clock

± 2 minutes/month (15 to 30 °C) Clock accuracy

Synchronisation NTP server or GPS

ENVIRONMENTAL CONDITIONS. GENERAL INFORMATION

Operating temperature without UPS: -10 up to 15 up to 30 up to +55 °C

with UPS: 0 up to $\frac{15 \text{ up to } 30}{15 \text{ up to } 40}$ up to $\frac{15 \text{ up to } 30}{15 \text{ up to } 40}$

Storage temperature Base device: $-25 \text{ up to} + 70 ^{\circ}\text{C}$ −20 ... 60 °C (<1 month) Battery pack UPS:

−20 ... 45 °C (< 3 months)

-20 ... 30 °C (< 1 year)

Temperature influence 0.5 x basic uncertainty per 10 K Long-term drift 0.5 x basic uncertainty per year Application group II (EN 60 688) Others Relative air humidity <95 % without condensation Operating altitude ≤2000 m above MSL

Only to be used in buildings!

MECHANICAL PROPERTIES

Installation position Control panel installation Housing material Polycarbonate (Makrolon)

Flammability class V-0 according UL94, self-extinguishing,

not dripping, free of halogen

800 g (AM2000/AM3000), 400 g (AM1000) Weight

SAFETY

Current inputs are galvanically isolated from each other.

Protection class II (protective insulation, voltage inputs via

protective impedance)


Pollution degree


IP54 (front), IP30 (housing), IP20 (terminals) Protection


U: 600 V CAT III, I: 300 V CAT III Measurement category


DIMENSIONAL DRAWINGS AM1000

DIMENSIONAL DRAWINGS AM2000/AM3000












Panel cut-out

144







Panel cut-out

ORDER CODE

0F	DER CODE AM1000				
	BASIC DEVICE AM1000	_	6.	EXTENSION	
	With TFT display, for control panel installation	1	0.	Without	0
2.	INPUT FREQUENCY RANGE	•		2 relays	1
	Current transformer inputs, 42 50/60 69.5 Hz	1		2 analog outputs, bipolar (± 20 mA)	2
3.	POWER SUPPLY	•		4 analog outputs, bipolar (± 20 mA)	3
0.	Nominal voltage 100 230 V AC/DC	1		4 digital inputs passive	4
	Nominal voltage 24 48 V DC	2		4 digital inputs active	5
4.	BUS CONNECTION	_		Fault current detection, 2 channels	6
	Without	0		GPS connection module	7
	Ethernet (Modbus/TCP + web server)	1		Profinet interface	A
	RS485 (Modbus/RTU)	2		IEC61850 interface	В
	Ethernet (Modbus/TCP + web server) + RS485 (Modbus/RTU)	3		Temperature monitoring, 2 channels	C
5.	DATA LOGGER	O	7	TEST PROTOCOL	O
0.	Without	0		Without	0
	Periodic Data + events ¹⁾	1		Test protocol in German	D
	Disturbance recorder + events 1)	2		Test protocol in English	F
	Periodic Data + events + disturbance recorder ¹⁾	3	ΔCC	ESSORIES	ARTICLE NO.
	Torrodio Bata i evento i disturbance recorder	3		umentation on USB stick	156 027
				face converter USB <> RS485	163 189
				receiver 16x-LVS, configured	181 131
			Transformers for fault current detection see accessory current transformers		

¹⁾ Datalogger only possible for device variants with Ethernet

ADVANCED MONITOR



ORDER CODE AM2000				
1.	BASIC DEVICE AM2000			
	With TFT display, for control panel installation	1		
2.	INPUT FREQUENCY RANGE			
	Current transformer inputs, 42 50/60 69.5 Hz	1		
3.	POWER SUPPLY Naminal voltage 110	4		
	Nominal voltage 110 230 V AC, 130 230 V DC Nominal voltage 24 48 V DC	1 2		
	Nominal voltage 24 46 V DC Nominal voltage 110 200 V AC, 110 200 V DC	3		
4.	BUS CONNECTION	U		
	Without	0		
	RS485 (Modbus/RTU slave)	1		
	RS485 (Modbus/RTU slave) + Ethernet (web server)	2		
	RS485 (Modbus/RTU slave) +			
	Ethernet (Modbus/TCP protocol + web server)	3		
	RS485 (Modbus/RTU) +			
	Ethernet (Modbus/TCP + web server) +			
	data logger (periodic data + events)	4		
5.	EXTENSION 1			
	Without	0		
	2 relays	1		
	2 analog outputs, bipolar (± 20 mA) 4 analog outputs, bipolar (± 20 mA)	2		
	4 digital inputs passive	4		
	4 digital inputs active	5		
	Fault current detection, 2 channels	6		
	GPS connection module	7		
	Temperature monitoring, 2 channels	С		
6.	EXTENSION 2			
	Without	0		
	2 relays 2 analog outputs, bipolar (± 20 mA)	1 2		
	4 analog outputs, bipolar (± 20 mA)	3		
	4 digital inputs passive	4		
	4 digital inputs active	5		
	Fault current detection, 2 channels	6		
	GPS connection module	7		
	Profinet interface	Α		
	IEC61850 interface	В		
7.	Temperature monitoring, 2 channels EXTENSION 3	С		
٧.	Without	0		
	2 relays	1		
	2 analog outputs, bipolar (± 20 mA)	2		
	4 analog outputs, bipolar (± 20 mA)	3		
	4 digital inputs passive	4		
	4 digital inputs active	5		
	Fault current detection, 2 channels	6		
0	Temperature monitoring, 2 channels EXTENSION 4	С		
8.	Without	0		
	2 relays	1		
	2 analog outputs, bipolar (± 20 mA)	2		
	4 analog outputs, bipolar (± 20 mA)	3		
	4 digital inputs passive	4		
	4 digital inputs active	5		
	Fault current detection, 2 channels	6		
0	Temperature monitoring, 2 channels	С		
9.	TEST PROTOCOL Without	0		
	Test protocol in German	D		
	Test protocol in English	E		

poorpoor	90099000
1	2
3	4
999 999	999 999

EXTENSIONS AM2000/AM3000

Maximum one extension with analog outputs may be provided per device.

Extension 4 only possible for a variant without data logger.

ORDER CODE AM3000						
1.	BASIC DEVICE AM3000					
	With TFT display, for control panel installation	1				
2.	INPUT I FREQUENCY RANGE Current transformer inputs, 42 50/60 69.5 Hz	1				
3.	POWER SUPPLY	ļ				
0.	Nominal voltage 110 230 V AC, 130 230 V DC	1				
	Nominal voltage 24 48 V DC	2				
	Nominal voltage 110 200 V AC, 110 200 V DC	3				
4.	BUS CONNECTION					
	Ethernet (Modbus/TCP + web server)	1				
5.	Ethernet (Modbus/TCP + web server) + RS485 (Modbus/RTU) DATA LOGGER	2				
٥.	Without	0				
	Periodic data + events	1				
	Disturbance recorder + events	2				
	Periodic data + events + disturbance recorder	3				
6.	EXTENSION 1	0				
	Without 2 relays	0				
	2 analog outputs, bipolar (± 20 mA)	2				
	4 analog outputs, bipolar (± 20 mA)	3				
	4 digital inputs passive	4				
	4 digital inputs active	5				
	Fault current detection, 2 channels	6				
	GPS connection module	7				
7.	Temperature monitoring, 2 channels EXTENSION 2	С				
7.	Without	0				
	2 relays	1				
	2 analog outputs, bipolar (± 20 mA)	2				
	4 analog outputs, bipolar (± 20 mA)	3				
	4 digital inputs passive	4				
	4 digital inputs active	5				
	Fault current detection, 2 channels GPS connection module	6 7				
	Profinet interface	A				
	IEC61850 interface	В				
	Temperature monitoring, 2 channels	С				
8.	EXTENSION 3					
	Without	0				
	2 relays	1				
	2 analog outputs, bipolar (± 20 mA) 4 analog outputs, bipolar (± 20 mA)	2				
	4 digital inputs passive	4				
	4 digital inputs active	5				
	Fault current detection, 2 channels	6				
	Uninterruptible power supply	8				
	Temperature monitoring, 2 channels	С				
9.	EXTENSION 4	0				
	Without 2 relays	0 1				
	2 analog outputs, bipolar (± 20 mA)	2				
	4 analog outputs, bipolar (± 20 mA)	3				
	4 digital inputs passive	4				
	4 digital inputs active	5				
	Fault current detection, 2 channels	6				
10	Temperature monitoring, 2 channels	С				
10.	TEST PROTOCOL Without	0				
	Test protocol in German	D				
	Test protocol in English	E				

ACCESSORIES	ARTICLE NO	
Documentation on USB stick	156 027	
Interface converter USB <> RS485	163 189	
GPS receiver 16x-LVS, configured	181 131	
Transformers for fault current detection see accessory current transformers		

SMARTCOLLECT



SMARTCOLLECT is a data management software which can acquire measured data in an easy manner and store the same in an open MS SQL database. This software offers basic functionalities for data analysis and for easy energy monitoring as well as the easy preparation and disposal of reports.

Providing a mature graphic user interface, the SMARTCOLLECT software is clearly structured and easily operated.

SMARTCOLLECT is modularly designed and permits supplementing modules or functions at any time.


CUSTOMER BENEFITS

- Easy data communication via Modbus RTU / TCP, ECL and SmartControl-Direct
- Connection also via OPC
- Devices of Camille Bauer and Gossen Metrawatt are already predefined and selectable in the software
- Open for the devices of all manufacturers
- Data is stored in an open MS SQL database (depending on the scope Express or Server)
- Modular cost / performance model basic version may be extended at any time

MODULAR DESIGN

COMPONENTS


The SMARTCOLLECT data management software consists of the following components:





GMC INSTRUMENTS

www.mod-tronic.com | sales@mod-tronic.com | 1-800-794-5883



MOD-TRONIC

